



IMPORTANT NOTES :

1. Cut hole through deck to accommodate the sleeve coupling to the bottom of corrugations.
2. Mount coupling to the corrugated metal with sheet metal screws, if necessary use a right angle metal strip to span the corrugations. (See component drawing No. P-43CM.)
2. After concrete is poured, remove protective cap.
3. Insert & solvent weld the P-90 pipe into the top of coupling.
4. Install the S-47 No-Hub adaptor from the P-90 pipe to other pipe.
5. Insert & solvent weld the E-Z Flex into the bottom of coupling. (See E-Z Flex instructions).
6. Connect other no-hub pipe or fitting into the E-Z Flex coupling.

Option 3 : Use when connecting fittings need to be close to the ceiling. E-Z Flex couplings are the easiest coupling to connect pipe & fittings.



W.H. Directory Reference 97 Edition
Firestop Device
W.H. Design No. PS/PH 120-01
F Rating 2 Hrs.



PROSET[®]
SYSTEMS
FIRESTOP PENETRATOR™

DATE :
09-02-2020
DRG . NO .
B-4803-C