


IMPORTANT NOTES:

- 1. Drill a 3" hole through the floor to accommodate the Riser support fitting.
- 2. Drill the proper size hole through the lower plate to accommodate water pipe size.
- 3. Insert the Riser support into the hole and secure with nails or screws.
- 4. Insert the pass through pipe through the bottom plate and Riser support fitting.
- 5. Install the proper size split ProSeal Plug around the pipe and drive into the Riser support.

Important: Use ProSet's White PrtoSeal Plug whe using CPVC pipe

For 1/2" through 1-1/2"Pipe.





DATE : 1-10-06

DRG . NO . A-1011-E