


PROSEAL PLUG DEVICE

CONCRETE ON CORRUGATED METAL DECK
FOR FLOORS



IMPORTANT NOTES :

1. Cut hole through the deck to accommodate the sleeve coupling to the bottom of corrugation.
2. Mount sleeve to the corrugated metal with sheet metal screws, if necessary use a right angle metal strip to span the corrugations. See component drawing P-43CM.
3. After concrete is poured, remove protective cap and solvent weld the 4" sleeve extension into the top of the sleeve coupling, if required.
4. Insert the pass through piping up through the sleeve coupling.
5. Install the proper size split ProSeal Plug around the pipe & drive in from top side.

Important: See drawing A-1010-AC or ACR for waterproofing



W.H. Directory Reference 97 Edition
Firestop Device
W.H. Design No. PS/PHV 120-03
F Rating 2 Hr. or 3 Hrs. or 4 Hrs.



PROSET[®]
SYSTEMS
FIRESTOP PENETRATOR™

DATE :
1-10-06
DRG . NO .
A-1010-C