


# PROSEAL PLUG SLEEVE ASSEMBLY

CONCRETE ON CORRUGATED METAL DECK  
FOR FLOORS



## IMPORTANT NOTES:

1. Cut hole through the deck to accommodate the coupling sleeve to the bottom of corrugations.
2. Mount coupling to the corrugated metal with sheet metal screws, if necessary use a right angle metal strip to span the corrugations. See component drawing No. P-43CM.
3. After the concrete pour, remove protective cap.
4. Insert the cables or pipes through the sleeve coupling.
5. Push the pipes or cables into the proper size split holes in the ProSeal Plug at one end of the sleeve coupling.
6. Drive the ProSeal Plug into the sleeve with a hammer.
7. When pass through pipe is insulated, cut the insulation at the top of the sleeve for the ProSeal Plug insertion.

**NOTE:** Various custom multiple openings are available through blank ProSeal Plugs, see component drawing P-10 for measurements.



W.H. Directory Reference 97 Edition  
Firestop Device  
W.H. Design No. PS/PHV 120-03  
F Rating 3 Hrs.



**PROSEAL**  
**SYSTEMS**  
FIRESTOP PENETRATOR™

DATE :

5-31-21

DRG. NO.

A-1003-C