


FIRE GUARD WASHER BOX

FOR POKING OUT OF GYPSUM OR MASONRY WALLS



IMPORTANT INSTALLATION NOTES :

1. Remove all parts from the package. Insert the four mounting brackets into the slots on both sides of the box. Set the brackets into the slots so the face of the box fits flush with the finished wall. Make sure the brackets are secured to the studs so the box is installed plumb and above the height of the washer.
2. Align the ball valves so the spouts point out of the box; tighten lock nuts. Connect water supply to valves. Solvent cement the 2" ABS or PVC drain pipe to the box opening. Install a test plug if testing is necessary.
3. The drywall cut out should be as close to the sides of the box as possible. Gaps of 3/8" or less can be filled with regular drywall cement. Gaps larger than 1/2" must be filled with an approved silicone caulk.
4. When the wall surface is completely finished, snap the face plate into the box to complete the installation.
5. Valves should always be turned to the off position when not being used.



W.H. Directory Reference 05 Edition
Firestop Device
W.H. Design No. PS/PV 120-08
F Rating 2 Hrs.



PROSET[®]
SYSTEMS
FIRESTOP PENETRATOR™

DATE :

5-31-21

DRG. NO.

C-8119-F