


SERIES 43 "CR" SLEEVE COUPLING EXTENSION WITH WATERGUARD



IMPORTANT NOTES :

1. Use nails through flange holes to mount the coupling to the various size recessed forms.
2. After the concrete pour, remove XH protective plug.
3. Insert and solvent cement a 3" long sleeve into the sleeve coupling to extend 2" above the floor.
4. Install the pass through pipe or fitting through the extended sleeve coupling.
5. Install ProSet's riser clamp around the pass through pipe to support and draft stop it.
6. When used for cast iron DWV, use regular no-hub clamps to connect the stack piping.
7. ProSeal Plugs can be used instead of the riser clamp for 1-1/2" & smaller pipe.

FUNCTION OF COMPONENT

This special sleeve coupling is made for waterproofing both the pass through pipe & the sleeve coupling while providing the required fire ratings through the floor.



PROSET[®]
SYSTEMS
FIRESTOP PENETRATOR™

DATE :
1-10-06
DRG . NO .
P-43-CR